3.More Functions

Battery Programming

KM Correction

Steering Angle Calibration

Key Code Learning

EABS Programming

Remote Manual Programming

4.Warranty And After–Sale Instructions

MINI OBD TOOL with one year warranty,and it is based on the date on the transaction voucher;If do not have transaction voucher or lost it,the factory date recorded by the manufacturer will prevail.

※ Situations on the below can not get free repairment

·Damage caused by not following the use instructions.

·Damage caused by repairing or retrofiting in private.

·Damage caused by fall,crash or inapproprate voltage.

·Damage caused by inevitable force.

·Damage caused by using in harsh environment or on the vehicle and ship for a long time;Get main body dirty and worn due to use.

Please get in contact with dealer or scan the QR code behind the instruction,download Xhorse official APP to get after–sale and technical support.

Due to product improvements, the contents of this manual may change without notice.

MINI OBD TOOL

User Manual

Xhorse MINI OBD TOOL

Overview

OBD Port

Signal Light
Red –Not connect
Blue –connection success

USB Port

MINI OBD TOOL is a multi–function vehicle programming tool with vehicle diagnosis、Immo Programming、Throttle program、Tire pressure light reset、maintenance light reset and etc.

MINI OBD TOOL can connect with specific software or hardware by WIFI、WLAN or interface.

1.Device Connection Success

① Connect To Device

Turn on KEY TOOL MAX, switch to MINI OBD TOOL interface,click [Select], available device will be shown on the screen,select correct device.

② Check Connection Status

Software will detect current device with software interface connection status、WLAN connection status and WIFI connection status

③ Device Connection Success

When KEY TOOL MAX success to connect to MINI OBD TOOL, Serial Number will be shown on the top of the screen.

④Disconnect Device

When MINI OBD TOOL finish the job,disconnect MINI OBD TOOL.

2.Main Functions

Immo Programming

Vehicle Diagnosis

Tire Pressure Light reset

Throttle Program

Maintenance Light Reset